



# Bevel Mate®

Bevel heads / Freeskoppen / Fräsköpfen / Cabezales de corte



Available in / Verkrijgbaar in / Erhältlich in / Disponible en



Steel  
Staal  
Stahl  
Acero



Premium  
Premium  
Premium  
Premium



Aluminum  
Aluminium  
Aluminium  
Aluminio



YouTube

[www.youtube.com/beveltools](http://www.youtube.com/beveltools)

Beveltools B.V.  
P.O. Box 190  
6880 AD  
Velp (Gld)  
The Netherlands

T +31 (0)26 369 92 22  
F +31 (0)26 369 92 23  
E [info@beveltools.com](mailto:info@beveltools.com)

Beveltools Inc.  
11426 Moog Drive  
Maryland Heights  
MO 63146  
United States

T +1 855 882 3835  
F +1 314 567 0124  
E [sales@beveltools.com](mailto:sales@beveltools.com)

# Quick Start Manual

## Bevel Mate® EBA-12




[www.beveltools.com](http://www.beveltools.com)




## Quick Start Manual Bevel Mate® EBA-12


### 1 • Mounting the bevel head




### 2 • Usage



### 3 • Adjusting the depth



### 4 • Bevel direction



### 5 • Maintenance

